



Notes:

- 1- Locate valve boxes in planting areas.
- 2- Wrap valve box with a minimum of 3 mil thick plastic and secure it using duct tape or electrical tape.
- 3- All threaded connection to be made using teflon tape.
- 4- All changes in elevation shall be made using Sch. 40 PVC 45° elbows.



BALL VALVE - 3" AND SMALLER