



**Note:**

- 1- Valve boxes shall be located in planting areas.
- 2- Splices shall only be made at electrical pull boxes.
- 3- Low voltage wires under roadways must be in continuous conduit with 90° Sch. 40 PVC sweeps terminating in pull boxes.
- 4- All wire connections shall be made using DBR/Y-6 connectors or approved equal.
- 5- Valve box shall be wrapped with minimum 3 mil. thick plastic and secure it using duct tape or electrical tape.



## ELECTRICAL PULL BOX (LOW VOLTAGE)