



Notes:

- 1- Prior to the start of work remove all thatch, sod, and/or weeds.
- 2- Loosen soil with Air Knife or approved equal to a depth of 9 - 12" and work around encountered roots.
- 3- Apply 2 - 3" of compost over loosened soil. Using an air knife mix compost into loosened soil.
- 4- Water entire root zone at end of each work day.
- 5- See planting soil specifications for additional requirements.

URBAN TREE FOUNDATION © 2014  
OPEN SOURCE FREE TO USE



## MODIFIED EXISTING SOIL - COMPACTED SOIL IN TREE DRIPLINE